
DS Lab 6- Message-oriented Communication


Name: Ozioma Okonicha

Course: SE-01

• Server/Receiver terminal



• Client/Sender terminal



• Screenshot of sending progress(receiver terminal)

```
sbuntuBjt-772-31-54-101:-/lab65 python3 server.py
[*] Listening as 1-pr72-31-54-101:-/lab65 python3 server.py
[*] Listening as 1-pr72-31-54-101:-/lab61 pitchines.ph.
[*] (*188.130-185.1351: $78580) is connected.

Receiving 50; report.pdf: $2.33 | 795k/1.48M [80:04-08:03, 230k8/s]

[*] (*188.130-185.1351: $78580) is connected.

[*] (*188.130-185.1351: $78580] is connected.

[*] (*188.130-18580] i
```

• Screenshot of sending progress(sender terminal)

```
Darle_KinaBozzie-Kina-KaZUNI-/Documents/3rd year 1st semester block_one/Distributed Systems/LabdS python3 client.py D5_report.pdf '54.237.47.10' 5000
[6] Obs sec... trying to comment to 54.237.47.19500
[6] Obs year... trying to comment to 54.237.47.19500
[6] Obs year... trying to comment to 54.237.47.19500
[6] Obs year... trying to comment to 54.237.47.19500
[7] Obs year... trying to comment to 54.237.47.19500
[8] Obs year... trying to comment to 54.237.47.19500
[8] Obs year... trying to comment to 54.237.47.19500
[9] Obs year... trying t
```

Screenshot of Is -la . output

• Well formatted source code

client.py

```
# import the necessary librabries
import socket
import tqdm
import os
import argparse
SEPARATOR = "<SEPARATOR>"
BUFFER SIZE = 4096
def send file(filename, host, port):
   # total file size read
   total = 0
   # get the file size
   filesize = os.path.getsize(filename)
    # create the client socket
   client socket = socket.socket(socket.AF INET, socket.SOCK STREAM)
   print(f"[+] One sec... trying to connect to {host}:{port}")
   client socket.connect((host, int(port)))
   print("[+] Yay, client successfully connected to the server!")
   # send the filename and filesize
   client socket.send(f"{filename}{SEPARATOR}{filesize}".encode())
    # progress bar to show transfer in percentage
   progress = tqdm.tqdm(range(filesize), f"Current progress of sending
{filename}", unit="B", unit scale=True, unit divisor=1024, leave=True)
    # prepare to read the file
   with open(filename, "rb") as f:
       for in progress:
            while total != filesize:
                # read the bytes from the file
                bytes read = f.read(BUFFER SIZE)
                # to check when file is done transmitting
                if total == filesize:
```

```
break
                # send the bytes from the client
                client socket.sendall(bytes read)
                # update the progress bar
                progress.update(len(bytes read))
                total += len(bytes_read)
    # close the file
    f.close()
    # close the socket
   client_socket.close()
if name == " main ":
    \ensuremath{\text{\#}} get the arguments to use in the function call
   parser = argparse.ArgumentParser(description="DS Lab 6")
   parser.add_argument("file")
   parser.add argument("host")
   parser.add argument("port")
   args = parser.parse_args()
   filename = args.file
   host = args.host
   port = args.port
    # call the function to send the file
    send_file(filename, host, port)
```

server.py

```
# import necessary librabries
import socket
import tqdm
import os
# total file size written
total = 0
# device's IP address
SERVER HOST =
socket.gethostbyaddr(socket.gethostbyname(socket.gethostname()))[0]
SERVER PORT = 5000 # remember to ensure that this port has an inbonud
rule in the ec2 instance
# receive 4096 bytes each time
BUFFER SIZE = 4096
SEPARATOR = "<SEPARATOR>"
# create the server socket
server socket = socket.socket()
# bind the socket to our address
server socket.bind((SERVER HOST, SERVER PORT))
# enabling our server to accept connections
server socket.listen(5)
print(f"[*] Listening as {SERVER_HOST}:{SERVER_PORT}")
```

```
# accept the client connection
client socket, address = server socket.accept()
# proof that the client is connected
print(f"[+] {address} is connected.")
# receive the file information
received = client socket.recv(BUFFER SIZE).decode()
filename, filesize = received.split(SEPARATOR)
# remove absolute path
filename = os.path.basename(filename)
# get the filesize
filesize = int(filesize)
# RENAMING DUPLICATES
# get the base name
base, ext = os.path.splitext(filename)
# get all contents of the current directory
contents = os.listdir()
copies = base + " copy"
num = []
# check if any copies already exist
for c in contents:
    # get all numbers of the copies
    if copies in c:
        i = int(''.join(x for x in c if x.isdigit()))
       num.append(i)
# if the file name already exists
if os.path.isfile(filename):
    # and there is no copy, create the first copy
   if len(num) == 0:
       base_copy = base + f'_copy{1}'
       os.rename(filename, base_copy + ext)
       # if there is a copy get the latest copy and increase the number by
one
       j = max(num) + 1
       base copy = copies + f'{j}'
       os.rename(filename, base copy + ext)
else:
   # doesn't exist, so we save it with the same name
    filename = filename
# start receiving the file from the client and writing to the file stream
progress = tqdm.tqdm(range(filesize), f"Receiving {filename}", unit="B",
unit scale=True, unit divisor=1024, leave=True)
with open(filename, "wb") as f:
   for _ in progress:
        while total != filesize:
                    # read bytes from the socket
```

```
bytes_read = client_socket.recv(BUFFER_SIZE)

if total == filesize:
    # finish transmission
    break

# write to the file the received bytes
f.write(bytes_read)

# update the progress bar
progress.update(len(bytes_read))
total += len(bytes_read)

# close the file
f.close()

# close the client socket
client_socket.close()

# close the server socket
server_socket.close()
```

• Link to GitHub repo or gist with source code.

lab6